





# Features and differences between Wi DMX\_pro, Wi DMX, Wi DMX\_easy and Wi DPc



<b>TRANSMITTER</b>	●	●	●	●
<b>RECEIVER</b>		●		
<b>EXTENDER</b>		●		
<b>Selectable DMX channel range</b>		●		
<b>LCD Display</b>		●		
<b>DMX OUT</b>		●		
<b>Radio Pairing</b>	●		●	●
<b>Radio frequency : 2.4 GHz - 2.483 GHz (ISM)</b>	●	●	●	●
<b>Radio Channels: 20</b>	●	●	●	●
<b>Transmitter Range: 1000 meters open air</b>	●	●	●	
<b>Transmitter Range: 500 meters open air</b>	●	●	●	●
<b>Backup function</b>		●		
<b>1 DMX 512 Universe</b>	●	●	●	●
<b>Fast Link</b>	●			
<b>SMA Antenna</b>	●			
<b>Compatibility with</b> 	●	<b>5 pin only</b>	●	●
<b>Compatibility with</b> 		●	●	●